



[www.graphicsone.com](http://www.graphicsone.com)  
[sales@graphicsone.com](mailto:sales@graphicsone.com)  
(818) 260 9591


# XPress 1620CS

## *USER MANUAL*



# NOTICE

- 1. Use the heat transfer press only as intend
- 2. Please keep children away from the machine
- 3. Use correct power outlet before plugging in the device
- 4. Burns can occur from contact with hot surface
- 5. Please hold the handle firmly when machine is opening
- 6. Turn off the device when not in use and remove the power plug



# CONTENT

● In the Box	03
● Product Features	04
● Display Setting	05/06
● Transfer Parameters	07
● Troubleshooting	08

## XPress 1620CS Clamshell Heat Press (110v)



### In the box


1 x XPress 1620CS

1 x Power Cable

1 x Silicon Mat

1 x User Manual

## MACHINE INTRODUCTION



1. Control Display

2. Heating Plate Cover

3. Silicone Mat

4. Alu. Lower Plate

5. Handle Grip

6. Handle Bar


7. Power Switch

8. Machine Base







9. Power Outlet




10. Pressure Knob





# CONTROLLER PROGRAM



**heatpress**  
IT9300

**PV** : Present Value  
**°C** : Celsius Read-out  
**°F** : Fahrenheit Read-out  
**S** : Timing in Seconds  
**888** : Temperature Digits  
 : Heating Indicator  
 : Timing  
 : Plus Digits  
 : Decrease Digits  
 : Set Mode  
 : Counter Clearance

**SV** : Set Value  
**888** : Temperature Digits  
 : Timing  
 : Decrease Digits  
 : Counter Clearance

**Buttons:**  
 CLEAR  
 TIME  
 AT  
 SET

# CONTROL SETTING



Control Panel Display



P-3 : °C or °F Read-out  
Touch SET & ↑↓ buttons to set °C or °F



Auto-off Introduction  
It reads OFF and machine starts to cool down after machine raises to SET temp. and remains no operation for P-4 set time. Operation like control panel setting or heat pressing.



P-1 : Temp. Setting Mode  
Touch SET & ↑↓ buttons to set desired Temp.



P-3 : °C or °F Read-out  
Touch SET & ↑↓ buttons to set °C or °F



Wake Machine from Sleepy Mode  
You can wake up the heat press from sleepy mode by touching any button on the control panel, and machine starts to heat again.



P-2 : Time Setting Mode  
Touch SET & ↑↓ buttons to set desired time.



P-4 : Auto Power-off Mode  
Touch SET & ↑↓ buttons to set auto-off time with 0-120 mins range



Clear Counter NO.  
You can long hold the CLEAR button to clear the COUNTER NO. on the panel.

# Transfer Parameters

TRANSFERS	PRINTHEAD	MARK	TEMP.	TIME	PRESSURE
SubliMate Paper	TFP, DX	Polyester Fabric	392°F	35sec.	Low to Medium
Fuze Fabric	TFP, DX	Cotton	385°F	35-40 sec.	Low to Medium

**For any further help, please contact  
our support team.**

**techsupport@graphicsone.com**  
**(818) 260-9591**

# Troubleshooting

**Q:When image is pressed onto garments, the color of the design is faded, or transfers are not fully transferred onto the garments.**

A: Test different points to get the right temperature, time and pressure.

**Q:The dye sub paper is stuck on the heating platen.**

A: You should use a Teflon sheet or parchment paper to cover the dye sublimation paper.

**Q: LCD control panel shows “000”.**

A: That refers the thermocouple wire is disconnected. Turn to support team for help by calling or emailing us directly.

**Q: How to get a reasonable pressure.**

A: Adjust the pressure by turning the knob and lock down the handle. There should be a larger resistant force soon after.

**Q: Turn on the power, but the heat press does not work.**

A: Pls check the power plug connected well to the socket, you may turn to support team if problem is still remaining.

**Q: Pressure knob is too hard to adjust.**

A: Adding lubricant oil to make the joint smooth.